AA - Repair Accessories

STANLEY,

AA Tool Motor Service Kits

| Descriptions | Part Number |
|--------------------------------|-------------|
| AA23 Motor Housing Service Kit | 20M103400 |
| AA33 Motor Housing Service Kit | 20M103401 |
| AA23 Motor Service Parts | 20M103450 |
| AA23 Motor Service Parts | 20M103451 |
| AA2/ 3 Handle Rebuild Kit | 20H104800 |
| AA2/ 3 Clutch Service Kit | 20G110400 |

Each of these tools is required to repair the AA motor. It is recommended to buy the complete kit once then any one of the components as needed when they wear out.

AA Motor Repair Tools

| Descriptions | Part Number |
|---|-------------|
| AA Motor Assembly / Disassembly Tool Kit (contains 1-each of the parts below) | 20V102400 |
| Motor Assembly Block | 20V202001 |
| Rear Bearing Press Tool | 20V102300 |
| Motor Bearing Removal Tool | 20V202600 |
| Motor Front Bearing Removal Tube | 20V203200 |
| Rear Bearing Removal Press Tool | 20V201900 |
| Motor Rear Bearing Removal Tube | 20V203300 |

20V102400 AA Motor Repair Tool Kit Parts

| Descriptions | Part Number |
|---------------------------------------|-------------|
| Throttle Seat Install Tool | 20V102000 |
| Throttle Lever Install Tool | 20V102100 |
| Rear Bearing Press Tool, AA2/3 | 20V102300 |
| A13-19 Assembly Tool | 20V200700 |
| Clutch Cam Assembly Install Tool | 20V201400 |
| Rear Brg Removal Press Tool, AA2/3 | 20V201900 |
| Motor Assembly Block, AA2/3 | 20V202001 |
| Motor Bearing Removal Tool, AA2/3 | 20V202600 |
| Throttle Seat Install Plug AA2/3 | 20V202800 |
| Motor Front Bearing Removal Tube | 20V203200 |
| Motor Rear Bearing Removal Tube | 20V203300 |
| ΩPM #3 Gear Case To Angle Head Socket | 20V204000 |

See AA Tool Manual for Use.